GATE VALVE	<u> </u>	CASING AND CARRIER PIPE	— <del>- = = = -</del> -
BUTTERFLY VALVE	<u> </u>	BLOW OFF VALVE IN MANHOLE	
BALL VALVE	<del></del>	COMBINATION AIR RELEASE/ VACUUM VALVE	
CHECK VALVE	<del></del> N	EXISTING MANHOLE WITH FLOW ARROW	— — — — — — — — — — — — — — — — — — —
PLUG VALVE (OPEN)	<del></del>	PROPOSED MANHOLE WITH FLOW ARROW	0+00
PLUG VALVE (CLOSED)	<del></del>	DROP MANHOLE	— —®*S− −
COUPLING		MANHOLE STUB OUT	
REDUCER		PROPOSED FIRE HYDRANT	
TEE		EXISTING FIRE HYDRANT	
CROSS	++	SERVICE CONNECTION	S
BEND	——————————————————————————————————————	METER & BOX	——□ WM
VERTICAL BEND	<del></del>		
CAP AT END OF LINE	<del></del> 11		
WTR/SWR SERVICE CONNECTION	T		
STANDARD DATE: 5/1994 DETAIL REV: 3/27/2007	UTILITY SYMBOLOGY - 3  N.T.S. el pa		el paso DETAIL No. 133